


Thank you for purchasing the **Alfresco Chaise Lounge**. This page lists all the contents included in the box. Please take time to identify the hardware as well as the individual components of this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Note: 2 people are required to safely assemble this product.

HARDWARE




2 - wheels



2 - small bolts
(pre-installed)


Missing hardware? Please call **800.606.6387** for replacements.

COMPONENTS



1 - chaise assembly


TOOLS REQUIRED



Phillips head screwdriver


(We recommend the use of hand tools instead of power tools)

ASSEMBLY



- 1) A) Remove 2 **small bolts** (pre-installed) from chaise assembly using a **Phillips head screwdriver**.
B) Insert **pin** of **wheel** into corresponding hole of **chaise assembly** as shown. Align hole in pin with hole in leg. Secure **wheel** to **chaise assembly** with 1 **small bolt** using a screwdriver. Make sure wheel is securely engaged by bolt. Do not over tighten the bolt. Repeat steps for remaining wheel.
Assembly is now complete.

ADJUSTING SEAT BACK



Pull *lever* out from underside of assembly, adjust *seat back* to desired height. Release lever to lock seat back into position.

Assembly is now complete.

CLEANING & CARE

Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. It is recommended to cover the chaise if left outdoors for the winter.

To remove small scratches, trays can be lightly sanded with a 0000 extra fine steel wool or very fine sand paper. Remember to always sand in the direction of the wood grain.