



Use and Care Instructions

Customer Service: 855-404-3300

Website: zippypop.com

Thank you for purchasing the Zippy Pop Stovetop Popcorn Popper & Snack Maker. Now you can enjoy perfect Popcorn every time or Roast Nuts and other savory SNACKS with any flavor your heart desires.

SAFETY PRECAUTIONS

- DO NOT leave pan unattended while cooking. Popcorn and other ingredients should be monitored continuously throughout the popping and roasting process.
- DO NOT place an empty pan on a heated stove top.
- Hot oil can burn or catch fire if left too long on heated stove top. Always attend heating of oil and do not heat it without adding other ingredients.
- DO NOT allow skin near a pan that contains hot oil. Hot oil may occasionally pop out of the pan while heating.
- USE an approved fire extinguisher to extinguish an oil fire. Never use water or liquid.
- DO NOT let children use the Zippy Snack Maker without adult supervision.
- DO NOT use Zippy Pop for other than intended use.
- DO NOT use Zippy Pop on induction stoves unless you purchase your Zippy with induction capability.
- Warranty voided if used for other than the specific purpose of popping popcorn, roasting nuts or making other snacks.

CARE OF ZIPPY SNACK MAKER

- Dishwasher Safe; recommend washing Zippy Snack Maker with non-alkaline soap.
- Wash pan thoroughly with hot, soapy water before initial use, rinse and air or towel dry.
- Expect some discoloration if alkaline soap is used. Discoloration will not hurt the performance of the product.
- Do not use metal utensils to cook or clean the non-stick interior.

Zippy Snack Maker Components

- Aluminum pot with Whitford Non-Stick Interior
- Tempered Glass Lid, Crank Handle with patented stainless steel tumbling mechanism.
- Silicone port cover insert
- Recipe pamphlet

Limited 2 Year Warranty

Zippy Pop Popcorn Popper and Snack Maker

What is Covered by this Limited Warranty? Zippy Pop warrants to you, **the original purchaser** of the Zippy Pop Popcorn Popper, that your product will be free of defects in materials and workmanship, including pot, lid and paddle mechanism.

What is Not Covered by this Limited Warranty? This limited warranty does not cover problems caused by normal wear and tear. It also does not cover problems resulting from external causes such as accident, abuse, misuse, mishandling, alteration, negligence, fire, theft, vandalism, natural disaster, or other acts of God. Also, it does not cover any problems resulting from a usage of the warranted product that is not in accordance with product instructions or resulting from a failure to follow product instructions.

This agreement is a product warranty and not insurance. No other warranty of any kind is made unless expressly provided herein. We disclaim all other warranties. Our liability will be no more than the amount you paid for the product that is the subject of a claim. This is the maximum amount for which we are responsible.

How Long Does this Limited Warranty Last? This limited warranty is good for 2 (two) years from the date of purchase. This limited warranty begins on the date of your proof of purchase, including, for example, your packing slip, invoice, or other receipt. The warranty period is not extended if we repair or replace a warranted product.

What Will You Do? Upon our review of answers to questions and inspection of proof of purchase and possibly pictures of the defective product (or the actual defective product) we will determine if your claim falls within the scope of this limited warranty. If we determine that it falls within the warranty we will send you a replacement product free of charge within sixty (60) days following our determination.

If we are not able to replace your warranted product because it has been discontinued or is not available we will either replace it with a comparable product or reimburse you for your purchase cost (as indicated on your proof of purchase), at our sole discretion. We will pay to ship the replacement product to you if you use an address in the United States (excluding Puerto Rico and U.S. possessions and territories). Otherwise, we will ship the product to you freight collect.

If we determine that the problem is not covered under this limited warranty, we will notify you and inform you of optional costs for replacing broken parts. Replacement products are covered for the remaining period of the limited warranty covering the warranted product that you bought. We own all warranted products returned to us that are exchanged for a replacement product.

May I Transfer This Limited Warranty? You may not transfer this limited warranty. This warranty coverage terminates if you sell or otherwise transfer a warranted product to another party.

What Should I do if I have a Question or Dispute?? If you have a question regarding the terms of this limited warranty or a complaint regarding its application please do not hesitate to contact us by mail or email at info@zippypop.com.